Help

How it works?

Version:1.0.0


This document takes you through different screen step-by-step to help you to operate lifts without touching its buttons.

Step 1

On launch of App, App will look if you are in any lift lobby as per your current location. Make sure you are inside lift lobby to properly use this App.



On successfully finding current lift lobby, App will show all the floors. Select your CURRENT floor where you are currently standing.



On selection of current floor,


• you will be asked to select UP/DOWN button as per floor

OR(As per Building Configuration)

• App will show all lifts that are in that particular lift lobby for you to select lift you want to call to your floor

ii CURO Elevate		<i>itcuro</i> Elevate	
Building 1 Floor (2) Lift Lobby Select Lift To Call At Your Floor		Building 1 Lift Selection	
LIFT LOBBY		Select Lift To Call At Your Floor	-
LIFT RECEPTION		Employee Lift 2	
		Employee Lift 3	
		Employee Lift 4	-
() UFTLOBBY	SCAN LIFT	A LIFT LOBBY	器 SCAN LIFT

App will take you to Waiting page, please wait on this page till lift arrives on your floor.



Once inside lift, SCAN lift QR code available inside lift next to lift buttons.



On Floor selection page, you will get option to select your destination floor As per building settings, you will have option to select multiple floors also

	ion Selection F		
20	19	18	17
16	15	14	13
12	11	10	9
8	7	6	5
4	3	2	1